



491 W. Garfield Ave., Coldwater, MI 49036
Phone: 517-279-2135
Web/live chat: www.bds-suspension.com
E-mail: tech@bds-suspension.com

Part#: 124320, 124321

Product: **Front Solid Sway Bar Links**

Application: **2007-2012 Jeep Wrangler JK**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

PARTS LIST

Part # Qty Description

124320 Box Kit

911110	2	Sway Bar Link
46	4	.750 x .120 x 1.450 Rolled Sleeve
SB34BK	4	3/4 ID Hourglass Bushing
B12X3G5	2	1/2 x 13 x 3 Grade 5 Bolt
N12PT	2	1/2 x 13 Prevailing Torque Nut
W12S	4	1/2in Washer

124321 Box Kit

911111	2	Sway Bar Link
46	4	.750 x .120 x 1.450 Rolled Sleeve
SB34BK	4	3/4 ID Hourglass Bushing - black
B12X3G5	2	1/2 x 13 x 3 Grade 5 Bolt
N12PT	2	1/2 x 13 Prevailing Torque Nut
W12S	4	1/2in Washer

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the OE front sway bar links from the sway bar and the axle. Save lower hardware.
3. Locate the new front sway bar links. Lightly grease and install the provided hourglass bushings (SB34BK and sleeves (46) into each end of the links.
4. Attach the new links to the outer mounting surface of each end of the front sway bar using a 1/2" x 3" bolt, nut and 1/2" washers. Install the links so that they offset toward the outside of the vehicle when installed. Run the bolt from the outside in. Leave hardware loose.
5. Attach the lower end of the new sway bar links to the inside mounting surface of the OE axle tab. Fasten the links with the OE sway bar link mounting hardware. Torque the upper and lower sway bar link hardware to 60 ft-lbs.