



491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: www.bds-suspension.com

E-mail: tech@bds-suspension.com

Part#: **124329**

Product: **Rear Sway Bar Drop Kit**

Application: **2007-2008 Jeep Wrangler JK**

**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR
TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Remove the four bolts (two per side) mounting the rear sway bar to the frame. Hardware will not be reused.
3. Place the provided spacers (01975) between the sway bar and the frame and align the holes in the frame, spacer and sway bar mounts. Fasten with the provided 10mm x 60mm bolts and washers. Torque bolts to 30 ft-lbs.
4. Check hardware for proper torque after 500 miles.