

#9906

Installation Instructions Manual Shift Extension Chevrolet/GMC

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Remove the four screws and four plastic fasteners holding the shift boot to the floorboard. Slide the shift boot up the lever out of the way.
2. Pull the rubber cover back to gain access to the spring plate. Remove the four screws mounting the spring plate to the top of the transmission. Remove the spring plate and lever from the vehicle.
3. Scribe a line along the lever below the bend. This line will be used to index the two pieces once the lever is cut.
4. Cut the lever through the line allowing for an adequate straight section of lever below the bend for the extension to mount.
5. Install the shift extension between the two pieces of the shift lever. Make sure the pieces of the lever seat all the way into the extension and the scribed lines are aligned.
6. Using a 1/8" drill bit, drill a hole through the two sections of lever and the extension using the existing holes in the extension as guides. Take care to drill through the center of the lever sections.
7. Install the provided 1/8" x 1" roll pins in the two holes and press them through the extension and the lever.
8. Install the lever back into the top of the transmission with the spring plate and retain with four OE screws.
9. Install the rubber cover.
10. Check the shift operation to ensure that all gears engage completely.
11. Slide the shift boot down the lever and attach it to the floorboard with the OE fasteners. Check lever operation to see that the boot does not bind.