




491 W. Garfield Ave., Coldwater, MI 49036
Phone: 517-279-2135
Web/live chat: www.bds-suspension.com
E-mail: tech@bds-suspension.com

Part#: 124411, 124414, 124424
Product: **Front Upper Control Arms**
Application: **Jeep**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
 2. Raise the front of the vehicle and support with jack stands under the frame rails just behind the lower control arm pockets.
 3. Coat with a thin layer of grease and install the provided bushings and sleeves in the new control arms. Install the provided grease fitting in the threaded hole. Index the fitting so that it points toward the body of the control arm.
 4. **Adjustable Arms Only (#124414, #124424):** Install the jam nut on the control arm followed by the female thread end. Adjust arm to desired length.
-  *Note: Factory Length is 15-1/8". Be sure that both driver's and passenger's arms are identical lengths.*
5. Support the front axle with a hydraulic jack and remove the passenger's side upper control arm. Retain hardware.
 6. Install the new arm so that the grease fitting is accessible. Fasten the arms in the OE locations using the hardware from bolt pack #738. Leave hardware loose.
 7. Repeat removal and installation on the driver's side. The axle can be raised or lowered to aid in aligning the axle mounting holes with the control arms.
 8. With both arms installed, lower the vehicle to the ground. Bounce the vehicle to settle the suspension and torque the four control arm bolts to 35 ft-lbs.
 9. If installing adjustable arms, lock off jam nuts.
 10. Grease the upper control arm bushings with lithium based grease.
 11. Check all hardware after 500 miles.
 12. Grease control arm bushings at every regularly schedule service.



NOTICE TO DEALER/INSTALLER

These instructions, the warning card, and included decals must be given to the owner of this BDS Suspension product.

For questions, technical support and warranty issues relating to this BDS Suspension product, please contact your distributor/installer before contacting BDS Suspension directly.

Sold/Installed by: